

HOW TO CREATE A PRINT-READY FILE:

Tension Fabric Frames

The following instructions are designed to help you create a print-ready file. If after reading them you are still unsure about anything, please download the template, visit the FAQ section of our website, request a professional File Check or contact customer support.

1 FILE FORMAT

Our systems can only process files in PDF format and in 1:1 scale (not password-protected).

2 COLOURS

All files must be sent in CMYK (cyan, magenta, yellow and black), with a Fogra 39 colour profile. Any images which are sent in RGB or in PANTONE colours will be automatically converted using a standard separation profile.

3 RESOLUTION


The optimal resolution for the print files is between 100 and 150 dpi.

4 TEMPLATE

To create a print-ready file for these products you must download the template from the website. Enter your artwork on a new layer, covering the entire area of the template, up to the green margin. Delete the guidelines, except the green line, and resave as a PDF. This will ensure your file prints correctly. Remember not to alter the scale of the artwork or resize the template.

Do not use spot colours when designing your artwork (they will not be printed).

GOOD TO KNOW



DOWNLOAD
THE TEMPLATE



INSERT YOUR
ARTWORK



DELETE ALL GUIDELINES
except the green line



SAVE THE PDF



PRINTED RESULT

5 ADDITIONAL INFORMATION

The minimum printable line weight is 0.5 pt.

The grey strips show the areas where the PVC edge (keder) will be sewn, used to insert the fabric into the frame. We recommend placing important text and graphics within the red safe area.

We do not advise placing frames and passepartouts too close to the edges, to avoid any uneven cuts around the perimeter.

